

TECHNICAL FEATURE

7EG 40GHLE 01 905



The + :

- Comfortable and airy surface
- Without staples nor seams
- Abrasion-resistant
- Instant changes of position
- Multiple adjustments
- Résiste à un usage intensif

ESD CHAIRS / POLYURETHANE

Chrome, 5-branch, scuff-resistant, reinforced base with antistatic glides

Chrome gas-lift column with height adjustment from 570 to 810 mm

and shock absorber

Height adjustable aluminium foot-ring

Ergonomic seat in antistatic black KANGO soft polyurethane

Independently adjustable seat and backrest tilt with one fingertip lever

thanks to an asynchronous mechanism

Backrest in antistatic soft polyurethane, adjustable in height

Special conductive polyurethane connects to the metal parts of the chair, allowing electricity to be discharged through carbon castors or pads