



### Standards

EN140: 1998 Mask Body  
EN143: 2000+A1: 2006 P3 RD  
EN166 Class 1.B.K.N. (Anti-Fog & Anti-Scratch)  
CE 2797

### Efficiency

P3 >99,95% for 0,3 µ particulate

### Weight

Mask + Filter: net (S/M) 203 g; (M/L) 211 g  
gross (S/M) 292 g; (M/L) 324 g  
Filter: net 18 g each; both net 36 g, gross 59 g

### Shelf Live

3 years (mask & filters) See storage conditions on Instructions for Use.  
Filters are re-usable and changeable.

### Material

- Mask:** Medical grade TPE Conforms to ISO 10993-10: 2010 for irritations. Mask body latex and silicone free, odour free. Valve Body in Nylon, Inhalation/Exhalation diaphragm in Silicone. 4 point adjustable elasticated head and neck strap with comfort pad in TPE.
- Filters:** Mechanical type multi-layer HESPA Synthetic media with TPE flexible overmolded / encapsulated. Glued additional carbon activated impregnated media.
- Goggle:** Polycarbonate with flow coating overmolded into soft TPE, permanently attached to the mask body by stainless steel clips.

### Production

United Kingdom  
100% of filters NaCl Tested

Code	Description	Quantity
SPR404(S/M) SPR405 (M/L)	P3 Elipse Integra complete with P3 filters	5 pcs. per box
SPR336	Elipse P3 Nuisance Odour replacement filters	10 sets of 2 pcs. per box
SPM007	Integra case	5 pcs. per box
SPM520	Peel off visor x 10	10 sets per box
SPM414	Portacount Face Fit Kit adaptor	50 sets of 10 pcs. per box

## Applications - dust, mist, fumes, ozone and smells



### Grinding

Metal Fumes, Ozone and Dust



### Construction

Silica Dust, Abestos, Concrete Dust, Stone Dust, Aggregate Dust, Wood Dust, Cement Dust, Mold



### Mining

Coal Dust, Silica Dust



### Manufacturing

Glass Fibres, Composite Fibres, Lead Fumes



### Food

Poultry, Powders (Dairy), Spices, Grain Dust



### Pharmaceutical

Powders, Viruses