

# SAFETY CANS & CONTAINERS

for Flammables



Swinging, full-fisted rounded handle eases carrying.

## Type I Safety Cans

### Self-closing, leakproof lid provides safety from spills

Designed with a single spout for filling and pouring, the sealed lid features automatic positive-pressure relief that vents between 3 and 5 psig (0.2 and 0.35 bar) to guard against rupture or explosion.

Made from high-grade coated steel, each can is tested to guarantee 100% leakproof construction. The tough powder-coat finish resists chemicals and stands up to demands of rigorous use. Each Justrite safety can is equipped with a stainless steel flame arrester which dissipates heat to stop flashback ignition. Cans up to 1 quart (1 L) feature a trigger-release handle, while larger capacities have a swinging handle to greatly ease carrying of heavier loads. Large label ID zone on swing-handle cans provides writing space to identify contents, department location, or individual user name.

Certified by FM, UL/ULC, and TÜV, Justrite safety cans also meet OSHA and NFPA requirements, and come with a ten-year warranty.

### Type I Safety Can Funnel

Used to pour into smaller openings, the polypropylene funnel attaches to the spout neck of Type I safety cans sized 1 gallon (4 L) and larger.

The two-position funnel folds down for when you fill or store the can, and stays up for when you pour. Large rounded bowl provides protection from splashing and spillage. Durable construction holds up to heavy use.



Convenient hinged design allows you to fill the can without removing the funnel.



10001 10101Z 10301Z



7125200Z 7150200Z



7150100Z



7125100Z



7120100Z



7110100Z

Description and Capacity	Dimensions OD x H	Approv/Lstg Regulation	Red Can Model No	Yellow Can Model No	Ship Wt lb/kg
<b>Trigger Handle Type I Safety Cans</b>					
1 pint (0.5 L) steel safety can	4.812 x 6.75 in 117 x 172 mm	FM, UL/ULC, TÜV	10001	10011Z	2/1
1 quart (1 L) steel safety can	4.812 x 8.25 in 122 x 210 mm		10101Z	10111Z	
1 gallon (4 L) steel safety can	7.25 x 11.5 in 184 x 292 mm	FM, UL/ULC	10301Z	—	4/2
<b>Swinging Handle Type I Safety Cans</b>					
1 gallon (4 L) steel safety can	9.5 x 11 in 241 x 279 mm	FM, UL/ULC, TÜV	7110100Z	7110200Z	4/2
2 gallon (7.5 L) steel safety can	9.5 x 13.75 in 241 x 349 mm		7120100Z	7120200Z	
2.5 gallon (9.5 L) steel safety can	11.75 x 11.5 in 298 x 292 mm		7125100Z	7125200Z	
5 gallon (19 L) steel safety can	11.75 x 16.875 in 298 x 429 mm		7150100Z	7150200Z	
Polypropylene funnel	.5 x 11.25 in 13 x 286 mm	—	11202Y	—	2/1
Replacement flame arrester for 1 pint (0.5 L) and 1 quart (1 L) only	—	—	11098	11098	
Replacement flame arrester for 1 gallon (4 L) and above	—	—	11007	11007	

