

for Cleaning and Dispensing

Dip Tanks

Use for cleaning parts and subassemblies where the volume of work does not warrant a larger rinse tank. Portable size accommodates changing production requirements. Dip tank covers stay open for convenient access; self-closing mechanism and fusible link melts at 165°F (74°C) to snap the cover shut in case of fire. Dip tank with polyethylene liner offers outstanding chemical resistance to permit use with the harsh, corrosive chemicals.



Description and Capacity	Dimension OD x H	Approv/Lstg Regulation	Red Model No	Yellow Model No	Ship Wt lb/kg
1 gallon (4 L) steel dip tank	9.375 x 5.5 in 238 x 140 mm	FM, TÜV	27601	27611	4/2
2 gallon (8 L) steel dip tank	9.375 x 10 in 238 x 254 mm		27602	27612	7/3
5 gallon (19 L) steel dip tank	13.75 x 13 in 349 x 330 mm		27605	27606	11/5
5 gallon (19 L) steel dip tank with HDPE liner		FM, TÜV	27615	27616	
8 gallon (30 L) steel dip tank	15.625 x 14.25 in 397 x 362 mm	FM, TÜV	27608	27618	13/6

Accessory Parts

Description	Dimensions: OD x H	Model No
Parts basket for dip tanks 27602, 27612	7.125 x 3 in 181 x 76 mm	27901Z

Bench Cans

An easy means of cleaning small parts in solvent, simply place work on spring-loaded, perforated dasher plate, press down and agitate, then release to return dasher to drain position. Plated steel dasher also works as an effective flame arrester to reduce the risk of fire flashback. Hinged cover minimizes evaporation losses and protected rim reduces the possibility of hand injury.



Description and Capacity	Dasher Diameter	Dimension OD x H	Approv/Lstg Regulation	Red Model No	Yellow Model No	Ship Wt lb/kg
1 quart (1 L) steel bench can	4.5 in 114 mm	4.875 x 5.5 in 124 x 140 mm	FM, TÜV	10175	10171	2/1
2 quart (2 L) steel bench can	7.5 in 191 mm	9.375 x 3.25 in 238 x 83 mm		10295	10291	4/2
1 gallon (4 L) steel bench can		9.375 x 4.5 in 238 x 114 mm		10375	10385	
2 gallon (8 L) steel bench can	9.75 in 248 mm	11.5 x 5.875 in 292 x 149 mm		10575	10578	9/4
Basket for 10375Z, 10385, 10575Z, 10578		6.4375 x .4375 in 164 x 11 mm	—	11171	—	1/1

Floor Standing Rinse Tanks

Self-close cover, operated by foot-treadle, allows a worker to open with both hands full. An adjustable-rate pneumatic cylinder prevents the cover from slamming shut when the treadle is released. Drain plug allows for easy solvent replacement.



Description and Capacity	Dimensions W x D x H	Overall Height	Approv/Lstg Regulation	Red Model No	Yellow Model No	Ship Wt lb/kg
22 gallon (83 L) steel floor standing rinse tank	32.75 x 16 x 12 in 832 x 406 x 305 mm	33 in 845 mm	FM	27220	27221	36/16



Accessory Parts

Description	Dimensions: L x W x D	Model No
Parts basket for rinse tank models 27220, 27221	28 x 13 x 4 in (711 x 330 x 102 mm)	27005
Sediment screen for rinse tank models 27220, 27221	35 x 13.75 x .75 in (889 x 349 x 19 mm)	27006