

▲ 2500 SERIES - 2520V



P2V Disposable Cup-Shape Respirator

The 2520V disposable respirator has a soft inner seal and offers outstanding levels of protection and fit. Suitable for protection against a broad range of particulate hazards.

KEY FEATURES

- ▶ Lightweight, cup shaped respirator
- ▶ Low profile exhalation valve to reduce heat and moisture build up
- ▶ Features a classic noseclip for a secure fit
- ▶ Soft Inner nose seal
- ▶ Continuous Loop Headstrap ensures easy fitting
- ▶ Conforms to EN 149:2001+A1:2009 FFP2 NR



ORDERING INFORMATION

Part Number: 2520V

Packaging: 20 singles per box
12 boxes per carton
240 singles per carton

Certification: EN149:2001+A1:2009
FFP2 NR

SUITABLE APPLICATIONS

Protects from non-toxic dust and oil/water based particulates. Some suitable applications include:

- **Manufacture of Batteries (Ni-Cad)**
- **Construction**
- **Infection Control**
- **Metalworking**
- **Mining**
- **Pharmaceutical Industry**
- **Ship Building/Repair**
- **Underground Civil Engineering**
- **Disposal of Waste**
- **Woodworking Industry**

A 2500 SERIES - 2520V



P2V Disposable Cup-Shape Respirator

TECHNICAL SPECIFICATIONS

MATERIALS

COMPONENT	MATERIAL
Outer Cover:	Polypropylene
Inner Cover:	Melt-Blown [Polypropylene]
Filter Media:	High Filtration Efficiency (Non-woven textile)
Nosefoam	Polyurethane
Headstrap:	Latex-Free Synthetic Rubber
Valve Cover:	Polypropylene

DIMENSIONS

ITEM	LENGTH (mm)	WIDTH (mm)	HEIGHT (mm)
Respirator	140	128	50

CERTIFICATION

EU certification according to Regulation (EU) 2016/425 issued by: BSI Group The Netherlands B.V. Say Building, John M. Keynesplein 9, 1066 EP Amsterdam, Netherlands [N.B. No. 2797].

RECOMMENDATIONS FOR USE

This respirator is disposable and recommended for single shift use only.

Do not attempt to clean or re-use.

PRODUCT SELECTOR GUIDANCE CHART

APPROVAL EN 149:2001 + A1:2009	PRODUCT CODE	APF (ASSIGNED PROTECTION FACTOR) (X WEL) ODOURS/ORGANIC VAPOURS)	NON-TOXIC DUSTS	FINE TOXIC DUSTS/MISTS/ FUMES	VERY FINE TOXI DUSTS/ MISTS/FUMES	METAL FUME	OIL/WATER BASED PARTICULATES
FFP2 NR	2520	10	■	■		○	■
FFP2V NR	2520V	10	○	■		○	■
FFP3V NR	2530V	20	○	■	■	■	■

■ = Recommended

○ = Alternative

▲ = Full Inner Face Seal

CAUTION This chart is for guidance only. Care should be taken when choosing the correct model to establish the type and concentration of hazard involved.

WEL = Workplace Exposure Limit A level of contamination (set by HSE) of the concentration of an airborne substance, above which level precautions must be taken if exposure takes place.

www.alphasolway.com T: +44 (0)1461 202452 E: alphasolway.sales@globusgroup.com

ALPHA SOLWAY LTD, Factory 1, Queensberry Street, Annan, DG12 5BL, UK

The descriptions, characteristics, applications and photos are given for information purposes and do not constitute a contractual commitment. The manufacturer reserves the right to make any modifications it deems necessary. © 2020 Alpha Solway Ltd

Part of
Globus
GROUP